# **Interface QubIDE sinclair QL instalation**

### **Step 1: QubIDE jumper configuration**.

It's necessary to indicate in with memory position will be the QubIDE EPROM. This position depends on Sinclair QL ROM and other extra interfaces are installed. Please read the <u>original explanation</u>.

## - ROM sinclair QL 48K: JM, JS, MINERVA, ....

Recommended option: 0C000h. J3, J4, J5 jumpers.



## - ROM sinclair QL 64K: JS+TK2, MINERVA+TK2,....

Recommended option:FC000h. No jumpers.



## Step 2: Connect the inteface to sinclair QL.

- Remove the left side cover of the Sinclair QL.

- Insert the interface.

- Note: Qubide connector sometimes is a bit lower that QL connector and It's a bit hard put the qubide.



Introduce the QubIDE until it reach the connector and then you will feel it aligns with sinclair QL bus connector. At that time apply some strength and the interface will introduce around 0.5 cm. QubIDE interface will fit in this way:



Step 3: Connect the IDE unit ( HD, CD-IDE or SD-IDE adapter, DOM ).

The QubIDE has been tested with the following adapters:







There are two SD-IDE adapters and a CF-IDE one. All of them work well but Compact flash unit may present a minor problem with geometry. In some cases the adapter must be modified to take power from the IDE connector pin 20.



Sinclair QL + QubIDE + CF-IDE adapter photo:

It has also been tested the **D**isk**O**n**M**odule :



**Step 4: Start sinclair Ql + QubIDE + IDE device**.

The first time you boot the sinclair QL, the following screen will appear:



- QubIDE ROM (1.56v) is displayed.
- There is a IDE device. In this example, a 32MB SD.
- The IDE device is not formatted.

**Step 5: Format IDE device**.

It's **very** important to read the <u>original explanation</u> before you format the IDE device. Depending on ram memory, IDE device capacity and the space you want to give to the primary partition, we must choose different options.

#### Example 1: SD device with with size <= 128MB.

- 32MB SD memory.
- One partition with all SD space.
- Small block size (8).



- The Sinclair QL format the SD making 2 passes.



#### Example 2: CF device with with size <= 128MB.

- **Important note**. To avoid "fat is wrong" problem, I recommend you know the geometry of your CF. I use the <u>Pera Putnik Drive image</u> program.

🔉 Drive image & ZX file transfer V 1.07 PP	2006	
Detected drives Homesite   0: 625140335 sectors = 305244 MB 1: Removable, 250880 sectors = 122 MB 2:   2: 3: 4: 5:   3: 6: 7: 8:   6: 7: 9: 9:   8: 9: 0 Sector rount 250880   RWinfo	Info Drive 1 selected Device desc.: STORAGE DEVICE CHS setting Sector/track: 32 Heads: 8 Cylinders: 980 Size CHS LBA	Create img. Open Image file File transfer Image format R H HDF W F 256 Read from drive Write to drive Quit

- 128MB Compact flash.
- One partition with all CF space.
- Don't use 0=all option
- you'll indicate the cylinders of the Compact Flash (In this example 980).
- Small block size (8). Other good size is 16

Format win1_ Formatting IDE win1_ How many cylinders ? Block size ? 8	(Ø=a())	980

**Example 3: Devices with with size > 128MB**.

If you have a IDE device bigger that 128MB and/or you want to have multiple partitions, you will have to use the **partition\_exe** that come on the QubIDE disk utility 2.01 version (The 1.56 version of **partition\_exe** application does not work). This program can be downloaded at:

#### Dilwyn page

After downloading the disk, take the partition\_exe program and introduce it in your IDE

device using this <u>tutorial</u>. Start the sinclair QL (preferably in monitor mode) and run **EXEC\_W WIN1\_PARTITION\_EXE**. It'll appear a screen similar to this one:

Oublide Partition Handware detected as DL Dublide mnently attached: Thack's Heads Secs. Online None Oniciae 3 32. SonDisk SDCFH-128 988 FRECTE TESC TO BURKO III 

In this example, **partition\_exe** program detect a 128MB Sandisk Compact Flash. The program will ask you which drive you want to use (1). Press ENTER and then the program will ask you if the activity led is ON ( Ok in my CF adapter) and you'll press ENTER.

Now it'll appear the screen where you'll can create, delete, format your IDE device:

(				Port of contraction of the second sec			
	123456	Vin2_ vin3_	Stant 0 100 301	End 99 388 500	Size(%) 12 25 25	Blocks 8 8 8	
	7 8 000	hange (R) eijjor	ve (Z) ero ()	Plansat (10	ext Black	Quit	

In this example, there is a 12MB primary partition and two 25MB secondary partitions called **win2\_** and **win3\_**.

Note: The primary partiton can not be create or modify with **partition\_exe** program. First use **device with size <= 128MB** tecnic to create it (max size is 128MB) and the use **partition\_exe** program to create secondary partitions. Please read the <u>original explanation</u>.

Once finished, we will close the application and reset the QL to take effect the changes.

2015 José Leandro Novellón